

---

---

## **CAE PERFORMANCE PRODUCTS PTY/LTD**

Pyrenees Hwy Chewton, VIC. 3450  
Telephone : ( 03 ) 5472 1442 - Fax ( 03 ) 5472 4111

---

---

### **Long Nose Water Pump Application**

- 1) Fit (2) thick wedge shaped spacers to the bottom engine holes near the drivers side of the harmonic balance, then fit the Alternator Bracket with the brace facing towards the radiator to the two bolt holes using suitable length bolts.
- 2) Mount the Alternator between this bracket with the 3/8 Bolt and Nylock nut provided.
- 3) Mount the top adjusting bracket to the alternator on the engine side of its mounting, then place the 18mm spacer between this bracket (bottom hole) and the top water pump mounting bolt.

### **Short Nose Water Pump Application**

- 1) & 2) Same as above – but no wedge type spacers required on the bottom engine holes.
- 3) Mount top adjusting bracket on the side of the Alternator top mount. No spacer required for the top water pump bolt. The bottom of the bracket mounts straight on to the water pump