

## **CAE PERFORMANCE PRODUCTS**

A.B.N. 37 340 926 19\83

7 MAIN ROAD, CASTLEMAINE, VIC.3450.

TELEPHONE: (03) 54721442 - FAX: (03) 54724111

Email: [info@caenterprises.com.au](mailto:info@caenterprises.com.au) Website: [www.caenterprises.com.au](http://www.caenterprises.com.au)

## Wiper Kit Components List.

Wiper Motor and Mounting Bracket Assembly

Wiper Tube Link Assembly

Wiring Loom, Switch and In Line Fuse

Customer Fitting Instructions.

## 59 Chev Wiper Kits Fitting Instructions

### (1) Fit new wiper motor assy. -----

Place connecting arm on motor shaft. Wire in switch and connecting Red wire thru fuse supplied to a suitable Ignition feed connection on the vehicle ignition switch. The Brown wire is to be connected to a suitable earth connection on the vehicle body

(2) Remove wiper arm and blades from windscreen. Test W/Motor

(3) Check Centre Link has come to the Park position

(4) If Step (3) is OK, reposition the Arm and Blades to the correct parking position. Wet windscreen and retest. If the park position has to be adjusted, use a 10mm tube socket to undo the wiper shaft nut inside the link tube,-- tap off the tube assembly and rotate to the position required, refit shaft nut and tighten firmly with the 10mm tube socket

